

IMPORTANT!

Rubber Flooring Floor Care Instructions

Please Read Below

Congratulations on your new flooring installation from Carpeturn.com! Please follow these instructions to maintain the manufacturer & installation warranties.



The adhesive under your floor needs time to thoroughly dry after installation. We recommend that you do not scrub or wash your floor for 72 hours.



Sweep or vacuum the floor on a regular basis. When using a vacuum cleaner, disengage the beater bar or use the “bare floor” setting to avoid damaging your Flooring.



If mopping is needed, use a damp mop with mild soap and water solution.



Do not use scouring pads, steel wool, sandpaper or other abrasive products.



Make sure that any cleaning agent that you use is not acidic, acetone based, and that it does not contain turpentine.



Limit direct sunlight by closing blinds the first 48 hours after installation. Failing to do so may result in curling and gapping of the planks do to the increase heat generated from the direct sunlight.

carpeturn.com[®]